

CV228 Firmware Update Instructions:

1. Prepare A USB to RS485 Phoenix terminal adapter (e.g. Marshall CV-USB-RS485) to connect between RS485 from camera breakout cable and PC USB port.
2. Set the camera baud rate to **115200** and CAM ID to **1** in camera OSD menu. Exit OSD menu completely.
3. Download firmware upload tool from Marshall website and install it.
4. Open firmware upload tool.
 - Select correct COM port, click “OPEN”
 - Click “Browse” to select firmware file
 - Click “Start” to update

