Marshall Electronics

Thank you for purchasing a Camera Top Monitor from Marshall Electronics.

We offer optional battery assemblies to fit the following Camera Top Monitors:

M-LCD7-B-C511	**M-CT7-C511**	**M-CT6-C511**
M-LCD7-B-CE6	**M-CT7-CE6**	**M-CT6-CE6**
M-LCD7-B-NEL3	**M-CT7-NEL3**	**M-CT6-NEL3**

These battery assemblies are designed to work with popular DSLR cameras by Nikon and Canon, and camcorders by Sony, Panasonic, JVC and Canon. Each battery assembly mounts directly onto the camera-top monitor with screws, providing a secure hold.

Battery assembly mounts securely onto monitor.

DSLR Batteries

BP-511-C	Canon BP511 Battery Assembly for M-LCD/ M-CT7	**$39.95***
BP-EN-EL15-N	Nikon NEL15 Battery Assembly for M-LCD/ M-CT7	**$39.95***
BP-EN-EL-N	Nikon E3e Battery Assembly for M-LCD/ M-CT7	**$39.95***
BP-LPE6-C	Canon E6 Battery Assembly for M-LCD/ M-CT7	**$39.95***

Camcorder Batteries

7-CGS-D54-PM	Panasonic CGA-D54 Battery Assembly	**$39.95***
7-NP-F970-SL	Sony NP-F970 Battery Assembly	**$39.95***
7-NP-QM91-SM	Sony NP-QM91 Battery Assembly	**$39.95***
7-VW-VBG6-PV	Panasonic VW-VBG6 Battery Assembly	**$39.95***
7-BN-V439U-JM	JVC BN-V438U Battery Assembly	**$39.95***
7-BP970G-CM	Canon BP-970G Battery Assembly	**$39.95***

AA Batteries

BP-6AA	AA Battery Assembly for M-LCD/ M-CT7	**$49.95***

**Batteries not included.*
**Pricing does not reflect freight costs and applicable taxes and/or duties.*
Pricing, specifications and features are subject to change at any time.

Please visit www.marshall-usa.com for more information about our Camera Top Battery Assemblies and for a complete listing of quality broadcast products from Marshall Electronics.

1910 E. Maple Ave., El Segundo, CA 90245 | www.marshall-usa.com | Toll Free: 1-800-800-6608 | (310) 333-0606